

## TECHNICAL DATA SHEET

# PENOSIL Neutral Sanitary Silicone 350

## Multipurpose neutral silicone

Neutral-curing silicone for sanitary and ventilation applications. Added fungicide gives excellent resistance to mould. Cures at room temperature under the action of atmospheric moisture to give a flexible silicone rubber.

### Main benefits

- Mould, UV and ageing resistant
- Household chemistry resistant
- Non corrosive to metals
- Non-sagging
- Great workability

### Fields of application

- All finishing, sanitation and ventilation sealing works.
- Filling, sealing, glazing, indoors and outdoors.
- Sealing connections of ceramic floors and walls, connections of washbasins, toilets, bath and shower tabs and shower glass.
- Filling and weatherproofing seams between window and door frames.



### Colour

Milky transparent.

### Package

300 ml cartridge, 12 pcs in a box.  
600 ml foil package, 20 pcs in a box.

### Storage conditions and shelf life

Guaranteed shelf life 12 months from the manufacturing date when stored in closed original package in a dry place and protected from direct sunlight at temperatures between +5 °C and +30 °C.

# PENOSIL Neutral Sanitary Silicone 350

## Adhering

- Concrete
- Masonry
- Wood
- Brick
- Aluminium (lacquered, anodized, painted)
- Galvanized steel
- PVC
- Glass
- Ceramics
- Most plastics

## Technical classifications and certificates

- Sealant used for sanitary applications  
EN 15651-3:2012: Type S: CLASS S1

## Technical data

Properties	Value	Unit
Basis	Oxime	
Density (DIN 53 479-B)	0,99	g/ml
Tack free time	2 ... 4	min
Skin forming time	5 ... 8	min
Curing Rate	2,0 ... 2,5	mm/24h
Loss of volume (ISO10563)	<20	%
Resistance to flow (ISO 7390)	0	mm
Intensity of microbiological grows (ISO 846)	0+	
Application temperature	+5 ... +40	°C
Service temperature	-40 ... +100	°C
Shore A hardness (ISO 868)	20 ... 25	
E-Modulus 100% (ISO 37)	0,34 ... 0,38	N/mm <sup>2</sup>
Tensile strength (ISO 37)	1,1 ... 1,6	N/mm <sup>2</sup>
Elongation at break (ISO 37)	>400	%
E-Modulus 100% (ISO 8339)	0,2 ... 0,35	N/mm <sup>2</sup>
Tensile strength (ISO 8339)	0,25 ... 0,5	N/mm <sup>2</sup>
Elongation at break (ISO 8339)	>200	%

The parameters indicated have been measured at +23 °C and 50% relative air humidity.

# PENOSIL Neutral Sanitary Silicone 350

## Application instructions

### Application conditions

Application temperature between +5 °C and +40 °C.

### Surface preparation

The surfaces must be dry, clean from dust, loose particles and oil. Non-porous surfaces should be cleaned with solvent and a clean, non-fluffy cotton cloth. Solvent excess should be removed before evaporating with a clean cloth.

### Application method

**Cartridge:** cut off the threaded end of the cartridge and screw on the application nozzle for directing sealant. Cut the threaded end in a way where a suitable opening for application is produced. Place the cartridge together with the applicator in the gun and fill the installation nozzle with sealant, by repeatedly pressing the gun trigger.

**Foil package:** open the end of the foil pack and place the pack inside the gun so that the dosing nozzle keeps covering its open portion. Place the dosing nozzle on the open end and screw on the cap to close the tube. Cut the nozzle to create a suitable opening for dosing sealant.

Apply sealant in the joint by repeatedly and evenly pressing on gun trigger and smoothly dragging the nozzle along the joint. After application, smooth the surface with a suitable tool (e.g., spatula) and remove excess material.

If necessary, the adjacent surfaces of the joint should be protected to avoid staining. Usually, masking tape is used for this.

Protective masking tapes should be removed before the sealant's skin is formed.

In wider and movable joints, backer rod should be used as a back-up material, to ensure the correct thickness and shape of sealant joint and to avoid three-sided adhesion.

Ensure adequate ventilation in all joint locations. During the curing process, make sure that no impurities can settle on the surface and that the joint surface is not affected by mechanical load.

### Cleaning

Uncured sealant can be cleaned with solvents like white spirit, acetone or with PENOSIL Cleaning Wipes. Cured sealant can be removed mechanically. If needed silicone remover should be used.

## Limitations

- Do not use on bituminous substrates or on building materials which might bleed oils, plasticizers or solvents (e.g. natural rubber, chloroprene, EPDM, ...).
- Due to the wide variety of polycarbonates, please test compatibility first.
- There is no adhesion to PE, PP, PTFE (Teflon®).
- We don't recommend this product to be used for natural stone sealing.
- Due to the wide variety of possible substrates, we recommend a preliminary compatibility and adherence test. If necessary, prime surfaces to improve adhesion.
- Due to the wide variety of influences during and after application, the customer must always test the product first.
- Please observe the expiration date!

# PENOSIL Neutral Sanitary Silicone 350

## Safety regulations

Ensure sufficient ventilation during application and wear necessary personal protective equipment.  
More specific safety information is available on the safety data sheet (SDS).

Note: The instructions in the present documentation are based on tests carried out by the manufacturer and are presented in good faith. Due to variations in materials and substrates as well as the various application possibilities that are beyond our control, the manufacturer is not liable for the results achieved. In any case, it is recommended to test the product suitability at the place of application. Manufacturer reserves the right to modify products without prior notice.  
This TDS replaces and supersedes all previous data sheets on the same product.

13-12-2024 16:35:24

Wolf Group Head Office  
Suur-Paala 10  
13619 Tallinn  
Estonia

Tel +372 605 9300  
Fax +382 605 9315  
info@penosil.com